

Instructions for commissioning the emsys Box



We are pleased that you have chosen our product. Please follow the steps below to successfully commission the emsys Box:

1. Step Plug a LAN cable into the "ETH1" port and connect it to the network at the other end, where the internet connection is provided.
2. Step ***Only if contractually separate networks have been specified:***
Plug a LAN cable into the "ETH0" port and connect it to the target device at the other end, where the target device is reachable.
3. Step Apply power by plugging the included power adapter into the green "PWR" connector.
4. Step Confirm the installation of the emsys Box via e-mail to **esb@emsysvpp.de**.